


Assessories



GWH40K

GWH10

**GWH 40K**


Art. no. 601166

Wall suspension with lock as protection against theft suitable for all EASYLog (except EASYLog 40NS W), EBN/K - ..., GIA 0420 WK and GRA 0420 WK

**GWH 10**

Art. no. 601169

simple wall suspension, made of stainless steel, suitable for all EASYLog (except EASYLog 40NS W).



EBSK

VSL

AKL 1P

**EBSK 01**

Art. no. 601173

Special plug with approx. 1 m of cable for connection of one EASYLog, to the EASYBus

**EBSK 03**

Art. no. 601174

Special plug with approx.3 m of cable for connection of one EASYLog, to the EASYBus

**EBSK 10**

Art. no. 601176

Special plug with approx.10 m of cable for connection of one EASYLog, to the EASYBus (Note: the EASYLOG will be supplied without connection cable. The GSOFT40K includes a connection cable EBSK01. Please order EBSK01, EBSK03 resp. EBSK10 as required in case of permanent bus connection!)

**VSL 2P**

Art. no. 601178

Twisted special cable for EASYBus-system, cross section 2 x 0,75 mm<sup>2</sup>

**AKL 1P**

Art. no. 601182

Special branch terminal for connection to VSL2P, 2 pieces



**GSM-3000**

Art. no. 607638

Alarm device

**General:**

Sending SMS when alarms occur. Connectivitye.g. for EB 3000, the GIA 20 EB or otherdevices with relay output or NPN switching output.

**Specifications:**

**LCD-Display:** with text display

**Inputs:** 6

**Outputs:** 4

**Miscellaneous:** SMS or call for up to 9 phone numbers  
Emergency battery  
SMS at power failure

**Scope of supply:** GSM alarm device, antenna for Screw on SMA connector, Fastening material, 9 V battery, Power supply, manual, connection instructions



**USB-Adapter**

Art. no. 601108

For connection of an interface converter with RS232 connection to the USB interface

Handheld instrument

Display / Controller

Logger- / Bus systems

Transmitter

Temperature probe

Assessories T-Logg



Ersatz-CR 2032



USB 100

**Ersatz-CR 2032**

Art. no. 606080

Spare battery for all T-Loggs

**USB 100**

Art. no. 602051

USB interface converter for connection to the PC

Simulators

Alarm / Protection, Level