GHM GROUP - Honsberg | GHM Messtechnik GmbH Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.ghm-group.de | info@ghm-group.de

Product Information

Flow Switch ABO-F012-S



- Complete flow switch in 12 mm housing .
- Can be used for various tubing cross-sections •
- Configurable switching point via plug pin (teaching) .
- Simple to use .
- Same form available for flow transmitter, temperature . switch / transmitter or level switch

Characteristics

The sensors of the LABO-F012 family are used for monitoring non-viscous fluids (for oil or gases on request). They come complete with electronics, and are supplied installed inside a compact sensor housing of 12 mm diameter and with M12x1 round plug outlet. The 16-bit processor carries out temperature compensation and linearisation of the calorimetric signal (measurement of the heat removal at the sensor tip by the flowing medium; for this see also the general description for calorimetry).

The electronics of the LABO-F012-S are a flexibly configurable limit switch.

The switching value can be set by the user via teaching (see Handling and Operation). All other values have been preset at the factory, but can be modified by the user with the aid of the optionally available ECI-1 interface and a PC.

The adjustable parameters are:

- Switching value .
- Hysteresis .
- Minimum/maximum monitoring .
- Switching delay •
- Switchback delay •
- Power-On delay •
- Teach-offset

Honsberg

C Member of GHM GROUP

LABO-F012-S

Technical data

Sensor	calorimetric measurement principle		
Process connection	push-in sensor Ø12 mm		
Switching range	water 2150 cm/s or 3300 cm/s		
	oil or gases available on request		
Measurement accuracy	dependent on the installation location and flow conditions typically ± 10 % of full scale value or 2 cm/s, of full scale value measured in the T-piece ± 5 %		
Repeatability	±1 %		
Start-up time	10 sec. after application of the operating voltage		
Response time	13 s		
Pressure resistance	Stainless steel compression PN 40 bar fitting		
	Plastic cone with union nut PN 10 bar		
Medium	-20+ 70 °C		
temperature	-20+100 °C (extended temperature range)		
Ambient	0+60 °C		
temperature			
Temperature dependency	± 0.01 % / 1 K		
Temperature gradient	4 K/s		
Materials medium-contact	Housing 1.4571		
Materials non- medium-contact	Plug PA6.6 gold-plated contacts		
Supply voltage	24 V DC ±10 % (controlled)		
Power consumption	< 2 W		
LED	yellow LED (On = Normal / Off = Alarm / rapid flashing = Programming)		
Electrical connection	for round plug connector M12x1, 4-pole		
Ingress protection	IP 67		
Weight	approx. 0.05 kg (excluding screwed connection)		
Conformity	CE		

Wiring



Connection example: PNP NPN



The use of shielded cabling is recommended.

Members of GHM GROUP:

GREISINGER | HONSBERG | Martens | / Jelta and | VAL.CO

GHM GROUP - Honsberg | GHM Messtechnik GmbH Tenter Weg 2-8 | 42897 Remscheid | GERMANY Phone +49 2191 9672-0 | Fax +49 2191 9672-40 www.ghm-group.de | info@ghm-group.de

ONSBER

Member of GHM GROUP

LABO-F012-S

Product Information

Dimensions



Optional accessories



Weld-on adapter

Compression fitting stainless steel



Weld-on adapter

Compression fitting plastic

LABO-F012... with measuring tube



DN	15	25	40	50
Process connection R	1/2"	1"	1 1/2 "	2"
Х	14	18	22	24
L	300	475	475	475
L1	90	100	200	200
Н	124	126	128	130

Members of GHM GROUP: GREISINGER I HONSBERG I Martens I Actacon I

VAL.CO

Handling and operation

Installation

There are various installation options available:

The stainless steel compression fitting is screwed into a G 1/2 threaded drilling. For this, a G 1/2 welded-on nozzle is also available. When a suitable seal is used, this arrangement can take pressures up to 10 bar. The stainless steel threaded connection is first tightened by hand, and then by $1/_4$ of a turn, using a spanner. The connection ring of the threaded connection can then no longer be removed from the sensor, and the immersion depth can therefore not be changed further.

The plastic cone is fitted to the separately available welded-on nozzle intended for this purpose, or to a suitable T-piece, using the union nut provided (available in brass or stainless steel). The union nut must be tightened to a torque of 20 Nm. It is possible to loosen the connection again, and so the immersion depth can be changed. This arrangement is suitable for pressures up to 10 bar.

When installing, it should also be noted that the sensors are directional (comply with the marking on the housing). The reduction of the sensor must be at 1/3..1/2 depth of the pipe diameter.

Avoid bubbles or deposits on the sensor. It is therefore best to install at the side.



Plug-in sensors with a measuring tube are delivered mounted in a measuring section. Since the adjustment was made in the factory in this measuring section, this version offers the lowest measurement uncertainty (typically ±5%).

The measuring sections are available in different nominal widths (DN15..DN50). They have an external thread on both sides for mounting in the application.

The sensor and the measuring section can be separated from each other, e.g. for cleaning. To do this, the union nut is loosened (only if the pipeline is pressure-free!) and the sensor is pulled out of the hole. The sensor has a permanently attached cone with an O-ring and a groove into which a pin engages on the opposite side. This prevents twisting and the sensor can only be inserted in one position in the measuring section.

Product Information

Operation and programming

The switching value can be set by the user by means of teaching. For this, proceed as follows:

- The flow which is to be set is applied to the device.
- Apply an impulse of at least 0.5 seconds and max. 2 seconds duration to pin 2 (e.g. via a bridge to the supply voltage or a pulse from the PLC), in order to accept the measured value.
- When the teaching is complete, pin 2 should be connected to 0 V, so as to prevent unintended programming.

The device has a yellow LED which flashes during the programming pulse. During operation, the LED serves as a status display for the switching output.

To avoid the need to transit to an undesired operating status for the purpose of teaching, the device can be provided ex-works with a teach-offset. The teach-offset point is added to the currently measured value before saving.

Example: The switching value is to be set to 80 cm/s, because at this flow rate a critical process status is to be notified. However, only 60 cm/s can be achieved without danger. In this case, the device would be ordered with a teach-offset of +20 cm/s. At 60 cm in the process, a switching value of 80 cm would then be stored during "teaching".

The LABO-F012-S limit switch can be used to monitor minimal or maximal.

With a minimum-switch, falling below the limit value causes a switchover to the alarm state. Return to the normal state occurs when the limit value plus the set hysteresis is once more exceeded.



With a maximum-switch, exceeding the limit value causes a switchover to the alarm state. Return to the normal state occurs when the measured value once more falls below the limit value minus the set hysteresis.



HONSBERG

O Member of GHM GROUP

LABO-F012-S

A changeover delay time (t_{DS}) can be applied to switching to the alarm state. Equally, one switch-back delay time (t_{DR}) of several can be applied to switching back to the normal state.

In the normal state the integrated LED is on, in the alarm state it is off, and this corresponds to its status when there is no supply voltage.



In the non-inverted (standard) model, while in the normal state the switching output is at the level of the supply voltage; in the alarm state it is at 0 V, so that a wire break would also display as an alarm state at the signal receiver. Optionally, an inverted switching output can also be provided, i.e. in the normal state the output is at 0 V, and in the alarm state it is at the level of the supply voltage.



A Power-On delay function (ordered as a separate option) makes it possible to maintain the switching output in the normal state for a defined period after application of the supply voltage. 4. 5.

HONSBERG O Member of GHM GROUP LABO-F012-S

Product Information



	1.	2.	3.
LABO-F012 -	S		Κ

O=Option

· ·			
1.	Switching output (Limit switch)		
	S	push-pull (compatible with PNP and NPN)	
2.	Sensor length L		
	100	123 mm	
	150	173 mm	
	200	223 mm	
3.	Sensor material		
	К	stainless steel 1.4571	
4.	Programming		
	N	cannot be programmed (no teaching)	
	P O	programmable (teaching possible)	
5.	Switching function		
	L	minimum switch	
	Н	maximum switch	
6.	Switching signal		
	0	standard	
	0 I	inverted	
7.	Optional		
	Н О	extended temperature range	

6. 7.

Options

Switching delay period (0.099.9 s) (from Normal to Alarm)	s .
Switch-back delay period (0.099.9 s) (from Alarm to Normal)	S .
Power-On delay period (099 s) (after connecting the supply, time during which the switching output is not activated)	s
Switching output fixed at	cm/s
Switching hysteresis Standard = 2 % of the metering range	%
Teach-offset (in percent of the metering range) <i>Standard</i> = 0 %	<u> </u>
Accessories	
• Cable/round plug connector (KB)	

- see additional information "Accessories" .
- ECI-3 device configurator (USB programming adapter) T-piece TS-3 for push in sensor Ø 12 mm with plastic-compres-•
- sion fitting
- Weld-on adapter •
- Compression fitting stainless steel •
- Measuring tubes (DN15...DN50) •
- safety chain kit

Members of GHM GROUP: GREISINGER | HONSBERG | Martens | Deltaces | VAL.CO